



NOTE:  
ALL WELDS TO BE  
PRESSURE WELDED  
WITH DWI-157-11-11

NOTE: START QUART SIZE  
WELDING AT 12 O'CLOCK  
AND PROCEED IN 90 DEGREE  
STEPS.

OPERATIVE EXTENSION WORK IN  
AGRICULTURE AND HOME ECONOMICS  
DEPARTMENT OF AGRICULTURAL ENGINEERING  
UNIVERSITY OF MARYLAND  
P. O. BOX 346, P. O. STATION, URBAN  
FARM, MARYLAND

YEAR	NO.	EX.	NO.	SHEET	OF
1965	14	EX	5791	SHEET	1 OF 1