



NOTE:
 TO INSTALL SYSTEM FOR MECHANICAL DRYING OF SMALL GRAINS ON EMB CORN, USE 500 BU. EMB CORN CRIB ON BIN FOR SMALL GRAINS. WHEN FRAMING, LATH BUILDING PAPER OVER JOINTS AROUND ALL DOORS & WINDOWS.