



HONEY UNCAPPING TANK



BASKET TO COLLECT WAX CAPPINGS




FRAME TO SUPPORT UNCAPPING TANK

NOTE:
THE UNCAPPING TANK IS USED TO OPEN THE COMBS BEFORE HONEY EXTRACTING. TWO BASKETS MAY BE USED LEAVING APPROXIMATELY 42" TO HANG UNCAPPED COMBS.

MATERIALS:

- FRAME** 2x2 x 8'-0" PINE
2x4 x 26'-0" PINE
1 LB. 10D NAILS
- BASKET** 1x2 x 8'-0" PINE
IS 1/2" x 5'-0" x 1/4"
MESH NOW, CLOTH
- TANK** 4'-2 3/4" 8'-6 3/4"
26 GA. GALVANIZED



SECTION THRU CONSTRUCTED TANK


HONEYCOMB UNCAPPING TANK

SCALE: NONE


BASED ON FLA. PLAN NO. 928




END VIEW



TOP VIEW



ISOMETRIC VIEW



SIDE VIEW

NOTE:
FINISHED UNIT SHOULD BE PAINTED WITH PAINT APPROVED FOR USE IN CONTACT WITH FOOD.

SUPER DUMPING BOARD

SCALE: NONE

BASED ON FLA. PLAN NO. 927

COOPERATIVE EXTENSION WORK IN AGRICULTURE AND HOME ECONOMICS

UNITED STATES DEPARTMENT OF AGRICULTURE COOPERATING AND HONEYCOMB UNCAPPING TANK AND SUPER DUMPING BOARD
USDA '80 EX. 8325 SHEET 1 OF 1