




SECTION "A-A"

ALTERNATE SECTION WITH PENS BACK TO WALL



PLAN

PERSPECTIVE  
(NOT TO SCALE)



WALK PLANK SUPPORT DETAIL

CONSTRUCTION NOTES:

- 1) BOLT FRONT AND BACK CRIB POSTS TO BEAM. NOTE THAT THE CRIB POSTS ARE CUT TO UNEQUAL LENGTHS TO MAKE THE CRIB FLOOR LEVEL. ALL WOOD PARTS BELOW WALKWAY LEVEL TO BE SOAKED IN WOOD PRESERVATIVE AFTER CUTTING AND BEFORE ASSEMBLY.
- 2) SET FRONT AND BACK PLYWOOD PANELS TO CRIB POST.
- 3) SET FLOOR JOISTS INTO CLEATS ATTACHED TO BEAM.
- 4) CUT FROM ONE END OF 4-0' x 6-0' STEEL MESH FLOOR PANEL, WELD ON STEEL ANGLE, AND SET MESH IN PLACE. DO NOT FASTEN MESH TO FRAMES SIDE PANELS. THESE SIDE PANELS CONCEAL THE WALK PLANK FEEDER.
- 5) SET IN STEEL FEEDER AND REMOVABLE PLYWOOD FLOOR PANEL IF DESIRED.

SCALE



COOPERATIVE EXTENSION WORK IN  
AGRICULTURE AND HOME ECONOMICS

UNITED STATES DEPARTMENT OF AGRICULTURE COOPERATING

WEANER CRIB

USDA '79 EX. 6319 SHEET 1 OF 1

(NOT TO SCALE)

NOTE: BASE ON CANADIAN PLAN NO. 3045